

Low Cost DCC (LC-DCC) 2.0
Controller Command Reference
8th April 2019

Summary

Provided in this document are the details of the LC-DCC controller serial and WIFI commands used for train control and programming.

Disclaimer

The designers accept no responsibility for any damage to any train or accessory decoder connected to this DCC system through incorrect assembly or use of the hardware design.

Please read s-9.1_electrical_standards_2006.pdf NMRA standard before purchasing and using a power supply. Also note some cheap power supplies can give over voltage output.

License / Usage Terms

All the software components are protected by license. When buying the software from eBay, you are entitled to one license which will be provided by Email. If you require multiple licenses then contact eBay seller.

Existing users of the 1.X design

Anyone using version 1.X of this design should be aware that the function of M3/M4 pins A6/A7/PC0/PC1/PB0/PB1 have been swapped. Users should check the latest build documents for version 2.0 onwards. Existing users will need to obtain a license key, this will be provided free if you have purchased via my eBay account. Users creating their own software who want to upgrade will also need to contact us to obtain an “unlock code” for the M3/M4.

LC-DCC Forum

A low cost DCC forum can be found at <http://low-cost-dcc.freeforums.net>, this was created in March 2019.

Buying On EBay

Please note that there are a number of false adverts on eBay that cannot provide support or valid updates for this project and may not even provide anything for your money. The idea of Low Cost DCC is to make available a quality product at a price that everyone can afford. Only buy from the designer and developer of this project. To ensure you are buying from the only official eBay listing check the seller information is as displayed below (seller: johncaffyn, location: Bristol). Any other listing is false.

The screenshot shows an eBay product page for a 'Low Cost DCC Controller 2amp or 10amp with CV programming and BlueTooth'. The listing includes a main image of a model train set, a 'Free postage' badge, and a 'Low Cost DCC 2.0' window. The product title is 'Low Cost DCC Controller 2amp or 10amp with CV programming and BlueTooth'. The seller is 'johncaffyn' with a 100% positive feedback rating. The price is £14.99. The listing features 'Buy it now' and 'Add to basket' buttons, as well as a 'Make offer' button. The seller information section shows 'johncaffyn' (253) with a 100% positive feedback rating. The listing also includes a '100% buyer satisfaction' badge, 'Click & Collect' option, and '162 watchers'. The collection method is 'Click & Collect - Select store at checkout'. The postage is 'Free Standard Delivery'. The delivery is estimated between Friday, 12 Apr. and Monday, 15 Apr. The payments section shows 'PayPal', 'VISA', and 'Processed by PayPal'. The returns policy is 'No returns accepted'.

Low Cost DCC Controller 2amp or 10amp with CV programming and BlueTooth

Condition: New

Quantity: 1

20 available

86 sold / See Feedback

£14.99

Buy it now

Add to basket

Make offer

Add to watch list

100% buyer satisfaction

Click & Collect

162 watchers

Collection: Click & Collect - Select store at checkout.

Postage: Free Standard Delivery | See details

Item location: Bristol, United Kingdom

Posts to: Worldwide

Delivery: Estimated between Fri, 12 Apr. and Mon, 15 Apr.

Payments: PayPal, VISA, Processed by PayPal | See payment information

Returns: No returns accepted | See details

Seller information

johncaffyn (253)

100% Positive Feedback

Contact seller

See other items

Have one to sell? Sell it yourself

Contents

Summary	2
Disclaimer.....	2
License / Usage Terms	2
Existing users of the 1.X design.....	2
LC-DCC Forum	2
Buying On EBay	3
Introduction	5
Controller Commands.....	6
Mode Control Commands.....	6
Power Control Commands	6
Licensing Commands.....	7
Configuration Commands	7
Status Commands	8
Service Mode Commands	9
Operational Mode Commands.....	10
Diagnostics Commands.....	11
Analogue Control Commands	12
LC-DCC RFID Train Location.....	12
Version Change History.....	13

Introduction

This book describes the serial and WIFI commands used by the LC-DCC system.

The LC-DCC system has three modes of operation:

- Idle
- Operational
- Service

In IDLE mode the controller generates only NMRA idle packets and no train control is possible.

In SERVICE mode the controller only responds to CV read and write commands.

In OPERATIONAL mode the controller responds to train and accessory control commands.

All commands are ASCII, there are two types of command: single character commands and multi character commands terminated by a line feed (ASCII decimal 10).

All error responses from the controller are preceded by an exclamation mark character (!).

Controller Commands

The following sections describe all the controller commands supported. The commands apply to both the WIFI and serial USB/Bluetooth designs.

Mode Control Commands

The following table defines the mode control commands:

Command	Controller Response	Description
M0	MODE-IDLE	Idle mode command.
M1	OP-MODE	Operational mode command.
M2	SERVICE-MODE	Service mode command.

All commands are terminated by a line feed and all responses are terminated by a line feed.

Power Control Commands

The following table defines the controller track power commands:

Command	Controller Response	Description
PA0	<i>None</i>	Disable track A power.
PA1	<i>None</i>	Enable track A power.
PB0	<i>None</i>	Disable track B power.
PB1	<i>None</i>	Enable track B power.

All commands are terminated by a line feed.

Licensing Commands

The following table defines the controller licensing commands:

Command	Controller Response	Description
?ID	XXXXXXXX-XXXXXXXX-XXXXXXXX-XXXXXXXX	Reads controller unique identification registers.
UC=xxxxxxxx	xxxxxxx or !UNLOCK	Unlock controller command to enable controller operation once a valid license has been detected.

All commands are terminated by a line feed.

The ID command returns four hexadecimal 32 bit numbers from the controller identification register.

The UC command receives an unlock code generated from the ID response as eight hexadecimal lowercase characters.

If you are developing your own software to use with the controller you will need to obtain an unlock code from support@swws.co.uk for each controller you build and use.

Configuration Commands

The following table defines the controller configuration commands:

Command	Controller Response	Description
NSS=28	<i>None</i>	Set engine speed default steps to 28.
NSS=128	<i>None</i>	Set engine speed default steps to 128.
LAM=0	<i>None</i>	Set long address mode off, 7 bit addressing.
LAM=1	<i>None</i>	Set long address mode on, 14 bit addressing.
ENLK=0	<i>None</i>	Engine locks off.
ENLK=1	<i>None</i>	Engine locks on.
ACLK=0	<i>None</i>	Accessory Locks off.
ACLK=1	<i>None</i>	Accessory Locks on.
FR=	<i>None</i>	Set engine function repeat sends value.
AR=	<i>None</i>	Set accessory repeat sends value.

All commands are terminated by a line feed.

Status Commands

The following table defines the controller status commands:

Command	Controller Response	Description
?CST	CST:a:b:c:d:e:f:g;h:i	Controller status query.
?TS	TS:AB:12345	Track status query.

The track status response TS is followed by the track power on/off status for track A and B followed by the current being read by the INA219 in milli-amps followed by line feed. When the either track is not powered a 0 (zero) is returned instead of A or B. If a current overload has been detected then the A/B status will be replaced by ** and the measured overload current will be returned.

The controller status response CST has the following fields:

Field	Description
a	Indicates if the long/short address mode is programmed and whether the speed steps have been configured
b	The number of speed steps, either 28 or 128
c	The address mode, either L for long address mode (14 bits) or S for short address mode (7 bits)
d	Function repeat setting, a value between 1 and 255
e	Accessory repeat setting, a value between 1 and 255
f	Engine locks setting either 1 for ON or 0 for OFF
g	Accessory locks setting either 1 for ON or 0 for OFF
h	The overload current setting in milli-amps or 0 if no INA219 detected
i	The maximum allowed overload current setting in milli-amps

Service Mode Commands

The following table defines the controller service mode commands:

Command	Controller Response	Description
WV	OK	CV write command to program CV.
RV	CV Value Read	CV read command to read CV value.

The WV command is followed by the CV number and the value to write, such as WV1=3 followed by a line feed.

The RV command is followed by the CV number to read, such as RV3 followed by a line feed. The response is CV followed by the CV number and value read, such as CV3=7 followed by a line feed.

Operational Mode Commands

The following table defines the controller service mode commands:

Command	Controller Response	Description
X	<i>None</i>	Generate NMRA DCC reset packets.
Y	<i>None</i>	Set engine control to 28 speed steps
J	<i>None</i>	Set engine control to 128 speed steps
Q	ES:	Query engine settings.
+	<i>None</i>	Increase engine speed.
-	<i>None</i>	Decrease engine speed.
0	<i>None</i>	Set engine speed to stop.
!	<i>None</i>	Emergent stop all engines.
>	<i>None</i>	Set engine direction forward.
<	<i>None</i>	Set engine direction reverse.
S	<i>None</i>	Set engine speed to value following S, for example S0, S28, S126
F0=	<i>None</i>	Set function F0 ON (1) or OFF (0)
F1=	<i>None</i>	Set function F1 ON (1) or OFF (0)
Fn=	<i>None</i>	Set function n ON (1) or OFF (0)
F28=	<i>None</i>	Set function F28 ON (1) or OFF (0)
FA=	<i>None</i>	Function values F0 and F1 to F4
FB=	<i>None</i>	Function values F5 to F12
FC=	<i>None</i>	Function values F13 to F20
FD=	<i>None</i>	Function values F21 to F28
FV=	<i>None</i>	Set engine sound volume value

Commands X,J,Y,Q,+,-,0,!,<,> are all single character commands without a line feed following them.

The function commands F0, F1 up to F28 use the same command format which is F0=1 for ON and F0=0 for function OFF etc.

The speed command S if followed by the step value; for example, S28, S0 can be used for engine stop.

All commands are terminated by a line feed.

The engine status response ES: has the following format: ES:a:b:c:d:e:f:g:h:i

a Engine address

b Engine Speed

c Function FA bits

d Function FB bits

e Function FC bits

f Function FD bits

g Engine Volume

h Engine Speed Steps

i Potentiometer controlling engine

Diagnostics Commands

The commands are available for diagnostics use only, they report various controller status information.

Command	Controller Response	Description
?LPB	<i>See Below</i>	Display processor DCC packet performance.
?ADC	<i>See Below</i>	ADS1115 ADC status.
?POT1	<i>See Below</i>	Display potentiometer 1 status.
?POT2	<i>See Below</i>	Display potentiometer 2 status.
?POT3	<i>See Below</i>	Display potentiometer 3 status.
?POT4	<i>See Below</i>	Display potentiometer 4 status.

?LPB Response

LPB=0,MW1=213,MW2=179,MPB=80

The late packet byte response shows how well the processor is generating DCC packet bits. The LPB indicates the number of times the processor has failed to meet a packet bit output deadline. The MW1 and MW2 show how much time is spare between the packet bit deadline and the processing of other interfaces such as UARTs and I2C buses. The MPB shows the maximum number of packet bits transferred in the longest packet byte sequence.

?ADC Response

ADC:EN=1,SR=-1,SV=13145

?POTx Response

P4,EN=1,VL=13147,SP=0,EA=2,AC=13207

P3,EN=0,VL=0,SP=-256,EA=0,AC=-1

The potentiometer number 1 to 4 follows a "P", followed by EN (enabled), VL (ADC value last read), SP (engine speed), EA (engine address) and AC (analogue centre reading for zero speed).

Analogue Control Commands

These commands are only supported if the ADC (ADS1115) is connected and the correct software is programmed into the M3 or M4 processor.

Command	Controller Response	Description
P1EA	<i>None</i>	Set the engine address to be controlled by POT1 ADS1115 A0 input.
P2EA	<i>None</i>	Set the engine address to be controlled by POT2 ADS1115 A1 input.
P3EA	<i>None</i>	Set the engine address to be controlled by POT3 ADS1115 A2 input.
P4EA	<i>None</i>	Set the engine address to be controlled by POT4 ADS1115 A3 input.

These commands program the engine address to be controlled when a potentiometer is connected to the ADS1115 input. Up to four engines can be controlled using the ADS1115 when a potentiometer is connected to each of the four ADS1115 analogue inputs.

An example command is P1EA=3 followed by a line feed. To disable the engine control potentiometer, use P1EA=0 for example.

LC-DCC RFID Train Location

The following table contains information related to the RFID train location system under development.

Command	Controller Response	Description
L	<i>None</i>	Send RFID location information to application.

This command is a location command sent from the RFID train location system and is forwarded by the LC-DCC controller to the connected PC and Android phone or tablet.

The format of the message is:

L<location><type><identifier> followed by a line feed, all numbers are hexadecimal.

For example

L00139876 <line feed>

Where 001 is the location of the RFID detector

Where 3 is the type, this allows engines and rolling stock to be identified separately

Where 9876 is always a four hex digit number for the engine/rolling stock identification

Version Change History

April 2019

Initial version.